



The wall opening should be checked for defects, such as, honeycomb and chipped edges. All defects must be rectified prior to window installation.

To facilitate proper positioning and installation of the window frame, the lower edge of the wall

opening should be levelled as discussed in Section 2.4.2. For brickwall, it is a good practice to provide a concrete kerb at the lower edge of the wall opening. For RC walls, the bottom edge of the wall opening should be made good with cement grout.

Figure 6.3: Base for siting of window frame

